



Installation Tips: Bleeding the System

1. The vehicle's battery should always be disconnected before any modifications are made.
2. Make sure all of the fittings in the power steering system are tight.
3. Raise all steering tires off of the ground.
4. Fill reservoir with power steering fluid (NEVER use automatic transmission fluid). Leave the cap off of the reservoir.
5. Cycle the steering from lock to lock three or four times.
6. Check fluid level in reservoir. Refill as needed.
7. Repeat steps 5 and 6 until a consistent level in the reservoir is reached.
8. Reconnect the battery. Replace the cap on the reservoir.
9. Start the vehicle and let it run without any steering input for 30 seconds.
10. Turn off engine.
11. Check and refill reservoir as needed, replacing cap when done.
12. Start engine and cycle steering from lock to lock 10-15 times.
13. Turn off the engine and let it stand for 10 minutes to allow air bubbles to work out of the system.
14. Repeat steps 11-14 until there are no air bubbles visible in the reservoir.
15. With the engine running, observe the fluid level in the reservoir. While looking in the reservoir, turn off the engine. The fluid level should not change.
16. If the level does not change, check the system for leaks. If there are no leaks, test drive the vehicle. If the level does change start over at step 4.

11468 S FM 730, Azle, TX 76020 USA 817-270-0102
www.pscmotorsports.com