

350 S. St. Charles St. Jasper, In. 47546 Ph. 812.482.2932 Fax 812.634.6632 www.ridetech.com

Part # 11146699 65-70 Buick Fullsize Rear Upper StrongArms

Components:


2	90001116	Upper StrongArm (Set to 12.75")
2	70013364	R-Joint threaded rod end housing
4	70013784	R-Joint Spacers

R-Joint Components

70013279	Retaining Ring
70013280	Wavo Wave Spring
70013276	R-Joint Composite Center Ball Cage
70013275	R-Joint Stainless Center Ball

Hardware:

2	99752004	¾" SAE Jam nut	R-Joint end
4	99501006	½" x 3 ½" USS Gr. 8 bolt	StrongArms
4	99502001	½" USS Gr. 8 Nut	StrongArms



Insert the SMALL end of the spacer INTO each side of the center pivot ball. Push the spacer in until it bottoms out in the center pivot.

STRONGARMS

Installation Instructions



- 1. The length of the upper bar should be set from the factory at 12.75" center to center. Ensure that the jam nut is tight.
- 2. Insert the Spacers into the R-Joints. Refer to Diagram 1 on Page 1.
- 3. Using the ½" x 3 1/2" bolt and Nylok nut supplied, fasten the R-Joint end to the frame bracket. An aluminum spacer must be installed on each side of the Heim end.



4. Fasten the other end of the bar to the axle using a ½" x 3 ½" bolt and Nylok nut.

Note: Inspect the rubber bushing in the axle for wear or cracked. Replace with factory replacement bushing if needed.

New R-Joints will be quite stiff (75-90 in/lbs breakaway torque) until they "break in" after a few miles of use. After the break in period they will move much more freely. Because the composite bearing race contains self-lubricating ingredients, no additional lubrication is needed or desired. Any additional lubrication will only serve to attract more dirt and debris to the R-Joint and actually shorten its life.