

### Installation Instructions



# Part # 11349572 - 1963-1964 C10 Steering Kit



### **Recommended Tools**



## **Major Components** .....In the box

QTY	Part Number	Description
2	90000091	Tie Rod Adjuster
2	99800002	5/8"-18 Right Hand Jam Nut
2	99800003	5/8"-18 Left Hand Jam Nut
1	90003043	Idler Arm
2	90003047	Outer Tie Rod End
2	90002918	Inner Te Rod End

#### **NOTES:**

This Tie Rod Adjuster is designed to take place of the OEM steel sleeve.

One end of the adjuster has a **groove** cut in it, this is the **LEFT HAND** threaded side.

When installing the Tie Rod Adjuster, use antisieze compound on the threads.

FOR YOUR SAFETY, THE TIE RODS NEED A MINIMUM 15/16" OF THREAD ENGAGEMENT INTO THE TIE ROD ADJUSTER. USE THE SIGHT HOLE IN THE SIDE OF THE TIE ROD ADJUSTER TO ENSURE PROPER THREAD ENGAGEMENT.