



350 S. St. Charles St. Jasper, In. 47546
Ph. 812.482.2932 Fax 812.634.6632

www.ridetech.com

Part # 13013699
Chrysler B & E Body Front Upper StrongArms

Upper StrongArms

1	90000602	Driver side upper arm
1	90000603	Passenger side upper arm
4	90000918	Bushings (Pressed into arms) - Moog # BR31
2	90000895	Ball joint – Proforged # 101-10126

ridetech

350 S. St. Charles St. Jasper, In. 47546
Ph. 812.482.2932 Fax 812.634.6632

www.ridetech.com



1. Remove factory upper arm.
2. Bolt StrongArm to frame using factory bolts. (Do not tighten yet.)
3. Slide ball joint boot over ball joint stud. Push stud through spindle. Torque the castle nut to 55 ft-lbs and tighten to align cotter pin hole. The supplied spacer may be needed to achieve proper castle nut to cotter pin hole alignment. Install cotter pin.
4. Install grease fitting and lubricate ball joint.
5. Position the suspension at ride height (about mid travel) and tighten upper arm bolt to 65 ft-lbs
6. Vehicle may need to be realigned before driving.

