




**INSTALLATION
INSTRUCTIONS**



Part # 11229122



**Rear Sway Bar
1964-1972 GM A-Body**




www.ridetech.com
812.482.2932





**Please Read And Understand All Instructions
And Warnings Prior To The Installation Of
This Product.**



THANK YOU

Congratulations on your new Ridetech product! It's an honor that you've selected the Ridetech brand to upgrade your ride. Our products are developed around quality and performance without compromise. We're confident you'll have many years (and miles) of pure driving enjoyment.
Thank you for choosing Ridetech!

Road Map

Sway Bar Installation

3

COMPONENTS			
Item #	Part #	Description	Qty
1	90002491	Rear Sway Bar	1
2	90002501	Control Arm Spacer	4
3	99431003	7/16-14 X 3 HCS GR5	4
4	99432001	7/16-14 NYLOK NUT	4
5	99433002	7/16 SAE FLAT WASHER	8

Sway Bar Installation

1. Some cars have a small hole near the front bolt location on the control arm. If yours has it, drill it out with a 7/16" drill bit and then mark a hole 6" to the rear of the first hole and drill a second 7/16" hole.

If your car has no holes, measure 10 1/4" back from the center of the front bushing and make a mark centered top to bottom. Next, measure back 6" from your first mark and mark a second hole location centered top to bottom. Drill the Locations with a 7/16" drill bit and go through both sides of the arm. Repeat for both Arms.

2. Insert the supplied spacer into the inside of the control arm at the hole locations. These spacers will be clamped in place by the mounting hardware after the sway bar is installed. These can also be welded in place if desired.

3. Position the bar in the car with the dip in the bar facing down. Install a 7/16" washer on one of the 7/16"-14 x 3" bolts and install one in each front hole to help hold it in place. Swing the sway bar into position and insert the rear bolt/washer. Tighten all hardware.





Figure 1



Figure 2



Figure 3